

TECHNICAL DATA SHEET

LevelMore RenoFibre®

01/02/26

A flexible, fibre-reinforced, fast-setting levelling and smoothing compound

Key Features

- Highly versatile – use on a wide range of internal domestic and commercial subfloors
- Outstanding workability and flow
- Sets with a smooth, consistent surface finish
- Protein-free formulation with high dimensional stability



Technical Information

Classification (EN 13813)		CT-C25-F6
Pack size		25kg
Water required per 25kg bag		5.75-6.25 litres
Application temperature (air and background)		≥ 5°C
Application thickness		2-40mm
@20°C	Working time	30 minutes
	Walk on	3 hours
	Tile after	4 hours
	Fit resilient floor coverings after	8 hours
Consumption per mm thickness (25% water)		1.6kg /m ²
Flow rate using a 30mm Ø x 50mm flow ring (EN 12706)		140-150mm
Compressive strength		>12 N/mm ² >20 N/mm ² >25 N/mm ²
Flexural strength		>3.5 N/mm ² >4.5 N/mm ² >6.0 N/mm ²

Areas of Use

Floors	Interior	Domestic and Commercial	Water Piped and Electric Underfloor Heating	Limited Movement/Vibration
--------	----------	-------------------------	---	----------------------------

Background and Surface Preparation

Backgrounds must be sufficiently dry and strong enough to carry the total weight being applied. All surfaces must be clean, sound and free from contaminants that could impair adhesion, such as dust, dirt, oil, grease, laitance, and curing agents. Timber bases must be rigid, stable and adequately ventilated. They should support both static and dynamic loads without deflection and be covered with an appropriate intermediate layer.

Suitable Floor Backgrounds				PRIMER REQUIRED
A Cement:Sand Screed (inc. Heated)	A Concrete	A Plywood Overlay (Class 3)	A Tile Backer Boards	PrimeMore Universal
B Asphalt (Flooring Grade)	B Epoxy DPM	B Existing Ceramic, Porcelain, and Natural Stone Tiles		PrimeMore Grip
C Calcium Sulphate/Anhydrite Screed (inc. Heated)				PrimeMore CS
A Prime with PrimeMore Universal diluted 1:3 with water. Depending on the porosity of the background, additional diluted coats may be required.		B Prime with one neat, undiluted coat of PrimeMore Grip.	C Prime with one neat, undiluted coat of PrimeMore CS.	

The primer must be allowed to dry before applying LevelMore RenoFibre.

Guidance Notes on Suitable Floor Backgrounds

Prime the following backgrounds with PrimeMore Universal, diluted 1:3 by volume with clean water (1 part primer to 3 parts water). Depending on the porosity of the background, additional diluted coats may be required. All coats must be touch dry before applying additional coats or the flooring compound.

CEMENT:SAND SCREED

Tile-Fixing (Porcelain & Ceramic):

- Allow new screeds to dry for at least 3 weeks.
- Direct fixing of agglomerate and some natural stone tiles will require extended drying times.
- For proprietary screeds, follow the manufacturer's recommendations for preparation and drying times.

Fitting Resilient Floor Coverings:

- Ensure the screed has an effective structural DPM and is dry ($\leq 75\%$ RH).
- If a structural DPM is absent or ineffective, apply One Coat DPM Fast or One Coat DPM Trade to the surface.
- PrimeMore MVS may be used where residual construction moisture is present up to 95% RH, whilst One Coat DPM Fast and One Coat DPM Trade are suitable for use up to 98% RH.

HEATED CEMENT:SAND SCREED

- New screeds must be commissioned from 3 weeks after screed installation and before work commences.
- Heat slowly at a maximum rate of 5°C per day until the maximum operating temperature is reached. Hold this temperature for 3 days before allowing the screed to cool to room temperature.

- For proprietary screeds, follow the manufacturer's recommendations for commissioning and preparation.

Fitting Resilient Floor Coverings:

- After commissioning, continue to run the underfloor heating until the screed is confirmed dry ($\leq 75\%$ RH).
- PrimeMore MVS may be used on prepared and commissioned heated screeds where residual construction moisture is present up to 85% RH. Alternatively, One Coat DPM Fast and One Coat DPM Trade may also be used on prepared and commissioned heated screeds.
- The underfloor heating should be switched off 48 hours prior to commencing work.

CONCRETE

Tile-Fixing (Porcelain, Ceramic, & Natural Stone):

- Allow new concrete to cure before being subjected to continuous air drying in good conditions for at least 6 weeks.
- Power floated concrete should be mechanically prepared to achieve a clean, sound, micro-textured, dust-free surface.

Fitting Resilient Floor Coverings:

- Ensure all concrete, including power floated concrete, has an effective structural DPM and is dry ($\leq 75\%$ RH).
- If a structural DPM is absent or ineffective, apply One Coat DPM Fast or One Coat DPM Trade to the surface.
- PrimeMore MVS may be used where residual construction moisture is present up to 95% RH, whilst One Coat DPM Fast and One Coat DPM Trade are suitable for use up to 98% RH.

Continued on next page...

- Power floated concrete must also be mechanically prepared to achieve a clean, sound, micro-textured, dust-free surface.

PLYWOOD OVERLAY (CLASS 3)

Fitting Resilient Floor Coverings:

- Plywood must be a minimum 6mm thick and conditioned to the appropriate moisture content for the environment.
- Fix using screw nails, ring shank nails, or screws every 100mm at the sheet's perimeter and 150mm elsewhere.

TILE BACKER BOARDS

- Must be installed as instructed by the manufacturer and be securely fixed to rigid, suitable, prepared bases.
- Where boards have been installed on solid bases using tile adhesive, ensure the adhesive has fully set before commencing work.
- Please note that some proprietary board manufacturers may specify a minimum compound thickness when installing certain floor coverings to prevent point-loading issues.

Prime the following backgrounds with one neat, undiluted coat of PrimeMore Grip. Allow the primer to dry before applying the flooring compound.

FLOORING GRADE ASPHALT

- Must be hard, sound and firmly adhered.

EPOXY DPM

- Must be a flooring grade that is compatible with cementitious products.
- Ensure it is hard, sound and firmly adhered.

EXISTING CERAMIC, PORCELAIN, AND NATURAL STONE TILES

- Must be in good condition, free from contaminants and well bonded.
- Ensure the existing structure can take the additional weight.

ADDITIONAL INFORMATION

Underfloor Heating: LevelMore RenoFibre can be used to encapsulate electric underfloor heating cables which have been adhered to prepared floors. For resilient floor coverings, it should be applied at the thickness recommended by the manufacturer to ensure the floor covering does not suffer heat damage.

After completing installations on backgrounds incorporating underfloor heating, the heating system should not be run for 10 days. Following this period, the floor temperature must be gradually raised to its optimal operating temperature, with an increase of no more than 2°C per day.

Impervious Backgrounds: To provide an absorbent base for the application of adhesives, when fitting resilient floor coverings, LevelMore RenoFibre must be applied at a minimum thickness of 3mm.

Timber Floors: LevelMore RenoFibre can be used to smooth or level uneven timber floors prior to overlaying with plywood or tile backer boards. The timber floor must be rigid, adequately ventilated and free of all contaminants that could impair adhesion and be primed with PrimeMore Grip. Allow the primer to dry before applying the compound, and the compound must be allowed at least 8 hours to fully dry before fitting the sheets or boards.

Multiple Layers: Where possible, LevelMore RenoFibre should be applied at the desired thickness in a single application. If required, additional layers – which must not exceed the thickness of the previous layer – may be applied once the compound is walkable and primed with diluted PrimeMore Universal.

Protein-Free: LevelMore RenoFibre is suitable for use in biologically sensitive areas.

Fitting Resilient Floor Coverings:

- If the existing tiles are fixed to a subfloor that does not contain an effective structural damp proof membrane, Kelmore DPM must be applied to the surface of the prepared tiles.

Prime calcium sulphate/anhydrite screeds with one neat, undiluted coat of PrimeMore CS. Allow the primer to dry before applying the flooring compound.

CALCIUM SULPHATE/ANHYDRITE SCREED

- All laitance and surface contaminants must be completely removed.

Tile-Fixing (Porcelain, Ceramic, & Natural Stone):

- The screed must be confirmed adequately dry ($\leq 85\% \text{ RH}$).

Fitting Resilient Floor Coverings:

- The screed must be confirmed dry ($\leq 75\% \text{ RH}$).

HEATED CALCIUM SULPHATE/ANHYDRITE SCREED

- All laitance and surface contaminants must be completely removed.

- New heated screeds must be commissioned from 7 days after screed installation and before work commences.
- The screed should be heated slowly and in accordance with the recommendations of the screed manufacturer.

Tile-Fixing (Porcelain, Ceramic, & Natural Stone):

- The screed must be confirmed adequately dry ($\leq 85\% \text{ RH}$).
- Switch off underfloor heating 48 hours prior to commencing work.

Fitting Resilient Floor Coverings:

- After commissioning, continue to run the underfloor heating until the screed is confirmed dry ($\leq 75\% \text{ RH}$).
- Switch off underfloor heating 48 hours prior to commencing work.

Mixing

Add 5.75-6.25 litres of clean, cold water to a clean mixing bucket. Gradually add one 25kg bag of LevelMore RenoFibre, and mix thoroughly using a paddle mixer until a smooth, lump-free consistency is achieved. The compound is ready for use immediately after mixing.

Application

Pour the mixed compound onto the prepared floor, then use a trowel, rake or pin leveller to regulate the thickness and guide the product into the desired areas. If the applied thickness allows, a spiked roller may be used within the working time to remove any trapped air and further enhance the surface finish.

Pumped Application

Mix according to the pump manufacturer's recommendations ensuring the correct water ratio is maintained. The mixed product should be smooth and fluid and have no surface separation or bleed. Flow checks should be performed regularly during the pumping process.

Drying

Drying times will vary dependent on the porosity of the background, as well as the ambient temperature, and humidity. When tested to the industry standard temperature of 20°C, LevelMore RenoFibre can be walked on after 3 hours. Porcelain, ceramic, and natural stone tiles after can be fixed after 4 hours, and resilient floor coverings can be installed after 8 hours. Please note that higher temperatures and low humidity will accelerate drying, whilst lower temperatures and high humidity will delay it.

Coverage

Coverage will vary dependent on the texture of the background and the application thickness of the product. The table below shows the approximate coverage of a 25kg bag of LevelMore RenoFibre when mixed with 6.25 litres of water.

Application Thickness	2mm	3mm	5mm	10mm	20mm	40mm
Approximate Coverage	7.8m ²	5.2m ²	3.1m ²	1.55m ²	0.78m ²	0.39m ²

Notes:

- Cementitious products should only be used when both air and background temperatures are 5°C or higher. If the temperature falls below 5°C, the chemical reaction required for the product to set is hindered, dramatically slowing the curing process. Normal setting will only resume once temperatures rise. However, if temperatures drop below freezing before the product has fully set, the integrity and performance of the product will be compromised.
- In conditions above 30°C, the product's setting time will be significantly accelerated, which could make it difficult to work with. When use in higher temperatures is unavoidable, steps must be taken to keep the air, background, water and products as cool as possible.

Cleaning: All tools should be cleaned with water after use and before the product sets.

Health and Safety: For full details, please refer to the Safety Data Sheet, available at www.kelmore.co.uk or by contacting Kelmore Ltd.

Storage and Shelf Life: When stored in unopened packaging, off the ground, and in cool, dry conditions, this product has a shelf life of 12 months.

BS 8203 & BS 5385: LevelMore RenoFibre should be used in conjunction with work carried out under the British Codes of Practice for the Installation of Resilient Floor Coverings, or for Wall and Floor Tiling.

All the information supplied by Kelmore Ltd is offered in good faith and is derived from the company's combined knowledge, experience and testing. Without prior notice, due to on-going research and development, the information we offer can be updated at any time. Kelmore's products are developed, tested and manufactured to consistently high standards, however, we accept no liability for any loss or damage which may arise from factors outside of our control, such as site conditions and/or the execution of the work.

